

DMC-2x00

Manual Rev. 2.1

By Galil Motion Control, Inc.

***Galil Motion Control, Inc.
270 Technology Way
Rocklin, California 95765
Phone: (916) 626-0101
Fax: (916) 626-0102
E-mail Address: support@galilmc.com
URL: www.galilmc.com***

Rev 03/2011

Using This Manual

This user manual provides information for proper operation of the DMC-2x00 controller. A separate supplemental manual, the Command Reference, contains a description of the commands available for use with this controller.

Your DMC-2x00 motion controller has been designed to work with both servo and stepper type motors. Installation and system setup will vary depending upon whether the controller will be used with stepper motors or servo motors. To make finding the appropriate instructions faster and easier, icons will be next to any information that applies exclusively to one type of system. Otherwise, assume that the instructions apply to all types of systems. The icon legend is shown below.



Attention: Pertains to servo motor use.



Attention: Pertains to stepper motor use.



Attention: Pertains to controllers with more than 4 axes.

Please note that many examples are written for the DMC-2x40 four-axes controller or the DMC-2x80 eight axes controller. Users of the DMC-2x30 3-axis controller, DMC-2x20 2-axes controller or DMC-2x10 1-axis controller should note that the DMC-2x30 uses the axes denoted as XYZ, the DMC-2x20 uses the axes denoted as XY, and the DMC-2x10 uses the X-axis only.

Examples for the DMC-2x80 denote the axes as A,B,C,D,E,F,G,H. Users of the DMC-2x50 5-axes controller, DMC-2x60 6-axes controller or DMC-2x70, 7-axes controller should note that the DMC-2x50 denotes the axes as A,B,C,D,E, the DMC-2x60 denotes the axes as A,B,C,D,E,F and the DMC-2x70 denotes the axes as A,B,C,D,E,F,G. The axes A,B,C,D may be used interchangeably with A,B,C,D.

<p>WARNING: Machinery in motion can be dangerous! It is the responsibility of the user to design effective error handling and safety protection as part of the machinery. Galil shall not be liable or responsible for any incidental or consequential damages.</p>
--

Contents

Using This Manual	ii
Contents	i
Chapter 1 Overview	1
Introduction	1
Specifications.....	2
DMC- 2000 Family Part Number Definition.....	2
Electrical Specifications.....	2
Mechanical Specifications.....	2
Environmental Specifications.....	3
Equipment Maintenance.....	3
Overview of Motor Types.....	3
Standard Servo Motor with +/- 10 Volt Command Signal	3
Brushless Servo Motor with Sinusoidal Commutation.....	3
Stepper Motor with Step and Direction Signals	4
Overview of Amplifiers.....	4
Amplifiers in Current Mode.....	4
Amplifiers in Velocity Mode.....	4
Stepper Motor Amplifiers.....	4
DMC-2x00 Functional Elements.....	5
Microcomputer Section	5
Motor Interface.....	5
Communication	5
General I/O.....	6
System Elements	6
Motor.....	6
Amplifier (Driver).....	6
Encoder.....	7
Watch Dog Timer.....	7
Chapter 2 Getting Started	9
The DMC-2x00 Main Board.....	9
The DMC-2000 Daughter Board.....	10
The DMC-2200 Daughter Board.....	11
Elements You Need.....	12
Installing the DMC-2x00.....	14
Step 1. Determine Overall Motor Configuration.....	14
Step 2. Install Jumpers on the DMC-2x00.....	15
Step 3a. Configure DIP switches on the DMC-2000.....	16

Step 3b. Configure DIP switches on the DMC-2100.....	17
Step 3c. Configure DIP switches on the DMC-2200.....	17
Step 4. Install the Communications Software.....	18
Step 5. Connect AC Power to the Controller.....	18
Step 6. Establish Communications with Galil Software.....	19
Step 7. Determine the Axes to be Used for Sinusoidal Commutation.....	21
Step 8. Make Connections to Amplifier and Encoder.....	22
Step 9a. Connect Standard Servo Motors.....	24
Step 9b. Connect Sinusoidal Commutation Motors.....	27
Step 9c. Connect Step Motors.....	30
Step 10. Tune the Servo System.....	30
Design Examples.....	31
System Set-up.....	31
Profiled Move.....	32
Multiple Axes.....	32
Objective: Move the four axes independently.....	32
Independent Moves.....	32
The motion parameters may be specified independently as illustrated below.....	32
Position Interrogation.....	32
The position error, which is the difference between the commanded position and the actual position can be interrogated with the instruction TE.....	33
Absolute Position.....	33
Velocity Control.....	33
Operation Under Torque Limit.....	34
Interrogation.....	34
Operation in the Buffer Mode.....	34
Using the On-Board Editor.....	34
Motion Programs with Loops.....	35
Motion Programs with Trippoints.....	35
Control Variables.....	36
Linear Interpolation.....	36
Circular Interpolation.....	37

Chapter 3 Connecting Hardware 39

Overview.....	39
Using Optoisolated Inputs.....	39
Limit Switch Input.....	39
Home Switch Input.....	40
Abort Input.....	40
Reset Input.....	41
Uncommitted Digital Inputs.....	41
Wiring the Opto-Isolated Inputs.....	41
The Opto-Isolation Common Point.....	41
Using an Isolated Power Supply.....	42
Bypassing the Opto-Isolation:.....	43
Analog Inputs.....	43
Amplifier Interface.....	43
TTL Inputs.....	44
The Auxiliary Encoder Inputs.....	44
TTL Outputs.....	45
General Use Outputs.....	45
Output Compare.....	45
Error Output.....	46
Extended I/O of the DMC-2x00 Controller.....	46

Chapter 4 Communication	47
Introduction	47
RS232 Ports	47
RS232 - Main Port {P1} DATATERM.....	47
RS232 - Auxiliary Port {P2} DATASET.....	47
*RS422 - Main Port {P1}.....	48
*RS422 - Auxiliary Port {P2}.....	48
RS-232 Configuration	48
Ethernet Configuration (DMC-2100/2200 only)	50
Communication Protocols	50
Addressing.....	51
Communicating with Multiple Devices.....	53
Multicasting.....	54
Using Third Party Software.....	54
Data Record	55
Data Record Map.....	55
Explanation of Status Information and Axis Switch Information.....	57
Notes Regarding Velocity and Torque Information	59
QZ Command	59
Controller Response to Commands	59
Unsolicited Messages Generated by Controller.....	60
Galil Software Tools and Libraries.....	60
Chapter 5 Command Basics	61
Introduction	61
Command Syntax - ASCII.....	61
Coordinated Motion with more than 1 axis	62
Command Syntax - Binary	63
Binary Command Format	63
Binary Command Table	64
Controller Response to DATA	65
Interrogating the Controller	66
Interrogation Commands.....	66
Summary of Interrogation Commands	66
Interrogating Current Commanded Values.....	66
Operands.....	66
Command Summary.....	67
Chapter 6 Programming Motion	69
Overview	69
Independent Axis Positioning.....	70
Command Summary - Independent Axis	71
Operand Summary - Independent Axis	71
Examples	72
Position Tracking.....	73
Example.....	75
Example.....	76
Trip Points.....	78
Command Summary – Position Tracking Mode.....	79
Independent Jogging.....	79
Command Summary - Jogging.....	79
Operand Summary - Independent Axis	79
Examples	80
Linear Interpolation Mode.....	81

Specifying the Coordinate Plane	81
Specifying Linear Segments	81
Additional Commands	82
Command Summary - Linear Interpolation	83
Operand Summary - Linear Interpolation	83
Example	83
Vector Mode: Linear and Circular Interpolation Motion	86
Specifying the Coordinate Plane	86
Specifying Vector Segments	87
Additional commands	87
Command Summary - Coordinated Motion Sequence	88
Operand Summary - Coordinated Motion Sequence	89
Example	89
Electronic Gearing	91
Ramped Gearing	91
Example	93
Command Summary - Electronic Gearing	93
Electronic Cam	95
Command Summary - Electronic CAM	98
Operand Summary - Electronic CAM	99
Example	99
Contour Mode	100
Specifying Contour Segments	100
Additional Commands	101
Command Summary - Contour Mode	102
General Velocity Profiles	102
Example	102
Virtual Axis	105
Ecam master example	105
Sinusoidal Motion Example	105
Stepper Motor Operation	106
Specifying Stepper Motor Operation	106
Stepper Motor Smoothing	106
Monitoring Generated Pulses vs. Commanded Pulses	106
Motion Complete Trip point	107
Using an Encoder with Stepper Motors	107
Command Summary - Stepper Motor Operation	107
Operand Summary - Stepper Motor Operation	108
Stepper Position Maintenance Mode (SPM)	108
Error Limit	109
Correction	109
Dual Loop (Auxiliary Encoder)	112
Additional Commands for the Auxiliary Encoder	113
Backlash Compensation	113
Example	113
Motion Smoothing	114
Using the IT and VT Commands:	115
Example	115
Using the KS Command (Step Motor Smoothing):	116
Homing	117
Example	117
Command Summary - Homing Operation	119
Operand Summary - Homing Operation	119
High Speed Position Capture (The Latch Function)	119
Example	120

